

# Communication System Accessories



MODEL: 2305CS/2308PC - CALL ORIGATION SWITCHES



2308PC



2305CS

## FEATURES

- Stainless Steel Face Plate
- Rugged Design and Construction
- Self-Wiping Switch Contacts
- Precious Metal Contact Surfaces

## SPECIFICATIONS

**2308PC:** 3-Position (“Privacy-Normal-Call”); Spring return from “Call” Position

**2305CS:** Momentary contact push-button type

**Dimensions:** Mounting Plate: 4 1/2" high (11.43 cm), 2 3/4" wide (6.94 cm)

**Mounting Holes:** 3 9/32" (8.33 cm) spacing

**Depth Required:** 1 3/4" (4.44 cm) minimum

**Finish:** Stainless steel

**Terminations:** 2305CS: Spade Lugs - pigtails  
2308PC: Spade

## DESCRIPTION

The 2308PC & 2305CS, are flush-mounted Call Origination Switches designed specifically for use with Rauland Telecenter® and Director® communications systems. Each features an attractive stainless steel faceplate with a rugged, reliable switch. The switch contacts are self-wiping to prevent erratic operation caused by accumulation of foreign materials and have precious metal contact surfaces for lowcontact resistance.

The 2308PC is a three-position switch designed for use in systems having call displays or annunciator lights, and including selective

privacy. The rocker mechanism has three positions: “off,” “call,” “privacy.” When placed in the privacy position, classroom privacy is absolutely assured, but the control center may still call the room.

The 2305CS pushbutton switch is ideal for use in systems having call displays or annunciator light call origination without selective privacy.

## ARCHITECTS AND ENGINEERS SPECIFICATIONS

**2308PC.** The Call Origination Switch shall be a Rauland Model 2308PC or approved equal. It shall be of the 3-position rocker type having a spring return “call” position. The switch contacts shall be of the self-wiping type and shall be fully enclosed. The switch shall be mounted on a single-gang stainless steel wall plate, with the rocker button having permanent die-stamped and filled designations.

**2305CS.** The Call Origination Switch shall be a Rauland Model 2305CS or approved equal. It shall be of the momentary contact pushbutton type and shall be fully enclosed. The switch contacts shall be of the self-wiping type with precious metal contact surfaces. It shall be mounted on a single-gang stainless steel wall plate.



Rauland is a Division of AMETEK, Inc.

USA +1 800 752 7725

Asia Pacific +65 64835750

[www.rauland.com](http://www.rauland.com)

Mid East & Africa +20 122 2154016

Europe +30 693 7501168

Latin America +1 847 454 4203

Architect and Engineer (A&E) Specifications available online at [customerconnection.rauland.com](http://customerconnection.rauland.com)  
Specifications subject to change without notice.