



MODEL: ACC1005 - DIGITAL CLOCK/SPEAKER BAFFLE



ACC1005
(Clock & Speaker not included)

FEATURES

- Handsome Matte Black Finish
- 20-Gauge, Cold-Rolled Steel Construction
- Mounts All 8" Speakers
- Ideal for Use With Rauland Digital Clock
- Designed for Flush Mount Installation

SPECIFICATIONS

Type: Recessed baffle
Application: 8" speaker and 1.8" character digital clock
Material: 20-gauge, cold-rolled steel
Finish: Matte black
Dimensions: 13.5" (34.3 cm) high, 11.5" (29.2 cm) wide

Weight: 1.5 lbs (0.7 kg)
Recommended Backbox: ACC1105

DESCRIPTION

The Rauland ACC1005 combination clock and speaker baffle is distinguished for its handsome appearance, durable construction and attractive value. It is designed for easy recessed installation not only to provide time display and enhanced audio reproduction, but also to provide an eye-pleasing baffle that blends well with any commercial decor.

The ACC1005 accommodates any standard 8" speaker and the

popular Rauland Model 2420 1.8" character digital clock. The ACC1005 Clock/Speaker Baffle is fabricated of 20-gauge, cold-rolled steel, finished in an attractive matte (flat) black enamel which is resistant to scratches and marring. The one piece design eliminates rattle. The proper backbox for the ACC1005 Baffle is the Rauland model ACC1105. All necessary mounting hardware is supplied with the baffle.

ASSOCIATED EQUIPMENT

Telecenter Communication Systems
ACC1105 – Flush Mount Square Backbox
2420 – 1.8" Digital Clock Module
USO188 – 8", 5 oz. Speaker

USO215 – 8", 10 oz. Speaker
USO216 – 8", 10 oz. Coaxial Speaker



Rauland is a Division of AMETEK, Inc.
USA +1 800 752 7725
Asia Pacific +65 64835750

www.rauland.com
Mid East & Africa +20 122 2154016
Europe +30 693 7501168
Latin America +1 847 454 4203

Architect and Engineer (A&E) Specifications available online at customerconnection.rauland.com Specifications subject to change without notice.