

# Speakers - Horns - Speaker Accessories

**Rauland**

MODEL: ACC1204A - SPEAKER ASSEMBLY



ACC1204A

## FEATURES

- Attractive walnut finish baffle
- Compact configuration for universal use
- High quality 8" speaker with 25/70 Volt line matching transformer
- Pre-assembled for installation convenience
- Matched components for quality performance
- "Whizzer" cone for extended high-frequency response

## SPECIFICATIONS

**Speaker Type:** 8" (20.3 cm) permanent magnet  
**Speaker Power Rating:** 10 Watts  
**Sensitivity:** 94 dB @ 1 meter with 1 Watt, 1 KHz input  
**Frequency Response:** 60 to 20,000 Hertz  
**Magnet:** 5.3 oz. ceramic  
**Voice Coil Impedance:** 8 ohms  
**Voice Coil Diameter:** 3/4" (1.9 cm)

**Transformer:** 25V/70V  
Taps @ 5/16, 5/8, 11/4, 21/2, & 5 Watts  
**Baffle Size:** H: 10 1/2" (26.7 cm)  
W: 9 7/16" (24.0 cm)  
D @ Top: 5 1/2" (14.0 cm)  
D @ Bottom: 3 3/4" (9.5 cm)  
**Weight:** 4 lbs. 9 oz. (2.1 kg)

## DESCRIPTION

The Rauland ACC1204A Speaker Assembly consists of a Rauland USO188A 8" loudspeaker complete with a 25V/70V line matching transformer mounted in a walnut finish MDF enclosure. The wide frequency response and superior efficiency of this speaker assembly make it an intelligent choice in both new and existing installations.

This high quality speaker with an attractive walnut finish and tapered enclosure will enhance the décor of any office or classroom

environment. The ACC1204A Speaker Assembly is particularly suitable for use in classrooms, meeting rooms, or small areas where surface mount speakers of excellent reproduction quality are required. Mounting hardware is included with each ACC1204A which is packaged as a complete, assembled unit to reduce installation time and expense.



Rauland is a Division of AMETEK, Inc.

USA +1 800 752 7725  
Asia Pacific +65 64835750

[www.rauland.com](http://www.rauland.com)

Mid East & Africa +20 122 2154016  
Europe +30 693 7501168  
Latin America +1 847 454 4203

Architect and Engineer (A&E) Specifications  
available online at [customerconnection.rauland.com](http://customerconnection.rauland.com)  
Specifications subject to change without notice.