

Speakers - Horns - Speaker Accessories

Rauland

MODEL: ACCWB5/ACCWB5VC - SPEAKER ASSEMBLIES



ACCWB5/ACCWB5VC

FEATURES

- Attractive acoustically-correct baffle
- Compact configuration for universal use
- High quality 8" speaker with 25V/70V line matching transformer
- Pre-assembled for installation convenience
- Matched components for quality performance
- Textured off-white epoxy semi-gloss finish
- "Whizzer" cone for extended high-frequency response
- Optional volume control with detachable knob to prevent unwanted volume adjustment

SPECIFICATIONS

Speaker Type: 8" (20.3 cm) permanent magnet

Power Rating: 8W RMS – 5 oz. magnet

Sensitivity: 93 dB @ 1 meter with 1 W input

Frequency Response: 65-17,000 Hz

Magnet: 5 oz. (141.7 g) ceramic

Voice Coil Impedance: 8Ω

Voice Coil Diameter: 3/4" (1.9 cm)

Transformer: 25V/70V; taps at 5/16, 5/8, 11/4, 21/2, & 5W

Baffle: ACC1003 - 22-gauge cold-rolled steel

Baffle Size: Square 11 1/2" (29.2 cm)

Width: 11 5/8" (29.5 cm)

Depth: 5 1/2" (14.0 cm) deep at top 3 1/8" (7.9 cm)
deep at bottom

Height: 1 13/8" (28.9 cm)

Weight: ACCWB5 – 4 lbs. 2 oz. (1.8 kg)

ACCWB5VC – 4 lbs. 4 oz. (1.9 kg)

DESCRIPTION

The Rauland ACCWB5 Series Speaker Assemblies consist of a Rauland USO188 8" loudspeaker complete with a 25V/70V line matching transformer, mounted in a Rauland ACC1003 Wall Baffle. These speaker assemblies are available with a 5 oz. (141.8 g) ceramic magnet.

The model with "VC" in the part number includes a volume control in the base of the enclosure. The volume control is located on the bottom side of the enclosure and features a detachable knob that facilitates administrator-only control.

The ACCWB5 Series Speaker Assemblies are particularly suitable for use in classrooms, meeting rooms, or small areas where surface mount speakers of excellent reproduction quality are required. They can be special-ordered in black. Mounting hardware is included with each Speaker Assembly and they are packaged as a complete unit, which reduces installation time and costs.



Rauland is a Division of AMETEK, Inc.

USA +1 800 752 7725

Asia Pacific +65 64835750

www.rauland.com

Mid East & Africa +20 122 2154016

Europe +30 693 7501168

Latin America +1 847 454 4203

Architect and Engineer (A&E) Specifications
available online at customerconnection.rauland.com
Specifications subject to change without notice.

Rev 05/2017 © 2017 Rauland. Printed in USA.