

Speakers - Horns - Speaker Accessories

Rauland

MODEL: ACCWB10 - SPEAKER ASSEMBLY



ACCWB10

FEATURES

- Attractive acoustically-correct baffle
- Compact configuration for universal use
- High quality 8" speaker with 25V/70V line matching transformer
- Pre-assembled for installation convenience
- Matched components for quality performance
- Textured off-white epoxy semi-gloss finish
- "Whizzer" cone for extended high-frequency response

SPECIFICATIONS

Speaker Type: 8" (20.3 cm) permanent magnet
Power Rating: 15W RMS – 10 oz. magnet
Sensitivity: 93 dB @ 1 meter with 1W input
Frequency Response: 65-17,000 Hz
Magnet: 10 oz. (283.5 g) ceramic
Voice Coil Impedance: 8Ω
Voice Coil Diameter: 3/4" (1.9 cm)
Transformer: 25V/70V; taps at 5/16, 5/8, 11/4, 21/2 & 5W

Baffle: ACC1003 - 22-gauge cold-rolled steel
Baffle Size: Square 11 1/2" (29.2 cm)
Width: 11 5/8" (29.5 cm)
Depth: 5 1/2" (14.0 cm) deep at top
3 1/8" (7.9 cm) deep at bottom
Height: 11 3/8" (28.9 cm)
Weight: ACCWB10 – 4 lbs. 7 oz. (2.0 kg)

DESCRIPTION

The Rauland ACCWB10 Series Speaker Assemblies consist of a Rauland USO215 8" loudspeaker complete with a 25V/70V line matching transformer, mounted in a Rauland ACC1003 Wall Baffle.

The ACCWB10 Speaker Assembly is particularly suitable for use in classrooms, meeting rooms, or small areas where surface mount

speakers of excellent reproduction quality are required. They can be special-ordered in black. Mounting hardware is included with each ACCWB10 and it is packaged as a complete unit, which reduces installation time and costs.



Rauland is a Division of AMETEK, Inc.

USA +1 800 752 7725
Asia Pacific +65 64835750

www.rauland.com

Mid East & Africa +20 122 2154016
Europe +30 693 7501168
Latin America +1 847 454 4203

Architect and Engineer (A&E) Specifications
available online at customerconnection.rauland.com
Specifications subject to change without notice.